FIT & SIZE CHART

CHEST SIZE

WAIST

MEASURING YOUR BODY FOR PROPER FIT:

Chest Size: Taken at the fullest point of your chest. Measure just under your arms and across shoulder blades holding the tape firm and level.

Waist: Measure around your natural waistline, keeping the tape snug, but comfortably loose.

Inseam: Measure from the base of your crotch to the top of your shoe. For a more accurate measurement have someone take this measurement. You can also measure a similar pant that fits you well. Lay the pant flat with the front and back creased smooth. Measure along the inseam from the crotch to the bottom of the leg hem.

XL

44-46"

2XL

48-50"

PLEASE NOTE: ALL VESTS ARE SIZED TO FIT **OVER YOUR WORK CLOTHES**

REG (34-42")

M

36-38"


32-34"

SIZE

CHEST SIZE

PLEASE NOTE: LUX ATRANS & LUX-ATRNSM RUN LARGER ON ALL SIZES

40-42"



1	2	3	4	5	6	7	8	9	10

4XL

56-58"

3XL

52-54"

FIT & SIZE CHART

2 3 4 5 6

CHEST SIZE

WAIST

MEASURING YOUR BODY FOR PROPER FIT:

Chest Size: Taken at the fullest point of your chest. Measure just under your arms and across shoulder blades holding the tape firm and level.

Waist: Measure around your natural waistline, keeping the tape snug, but comfortably loose.

Inseam: Measure from the base of your crotch to the top of your shoe. For a more accurate measurement have someone take this measurement. You can also measure a similar pant that fits you well. Lay the pant flat with the front and back creased smooth. Measure along the inseam from the crotch to the bottom of the leg hem.





PLEASE NOTE: ALL VESTS & JACKETS ARE SIZED TO FIT OVER YOUR WORK CLOTHES. ALSO, THE REFLECTIVE TAPE ON A T-SHIRT DOES NOT STRETCH. FOR A MORE COMFORTABLE LOOSER FIT, WE SUGGEST YOU BUY THE NEXT SIZE UP.

JACKETS

SIZE	S	М	L	XL	2X	3X	4X	5X
CHEST SIZE	34-36"	38-40"	42-44"	46-48"	50-52"	54-56"	58-60"	62-64"

1 2 3 4 5 6 7 8 9 10